


### **Instruction Manual**

Microwave Blind Spot Sensor System

RVS-122





Before Beginning Installation	03-04
System Specifications	<b>05</b>
Wiring	. 06
Installation	07-11
Alert Conditions	12
Troubleshooting	13
Warranty & Disclaimer	14-15



*If you have questions about this product, contact:* 

Rear View Safety
1797 Atlantic Avenue
Brooklyn, NY 11233
Tel: 1.800.764.1028

IN NO EVENT SHALL SELLER OR MANUFACTURER BE LIABLE FOR ANY DIRECT OR CONSEQUENTIAL DAMAGES OF ANY NATURE, OR LOSSES OR EXPENSES RESULTING FROM ANY DEFECTIVE PRODUCT OR THE USE OF ANY PRODUCT.

## of the wal of them be from

**BEFORE YOU BEGIN** 

Before drilling please check that no cable or wiring is on the other side of the wall. Please clamp all wires securely to reduce the possibility of them being damaged while vehicle is in use. Keep all cables away from hot or moving parts and electrical noisy components.


We recommend doing a benchmark test before installation to insure that all components are working properly.

PLEASE READ THE ENTIRE MANUAL AND FOLLOW THE INSTRUCTIONS AND WARNINGS CAREFULLY. FAILURE TO DO SO CAN CAUSE SERIOUS DAMAGE AND/OR INJURY, INCLUDING LOSS OF LIFE. BE SURE TO OBEY ALL APPLICABLE LOCAL TRAFFIC AND MOTOR VEHICLE REGULATIONS AS IT PERTAINS TO THIS PRODUCT. IMPROPER INSTALLATION WILL VOID MANUFACTURER'S WARRANTY.

#### **System Specifications**

4	
4.0-24.25GHZ	
15dbm	
40°C (Horizontal)	
Five objects can be detected simul-	
taneously	
0.5mph-137mph	
When GPS module is connected,	
notifications are activated over	
20mph / If no GPS module is con-	
nected, the system will give notifi-	
ations at any speed	
at any speca	
pproached or overtaken by vehi-	
cles	
Truck: 1ft-60ft / Car: 1ft-50ft / Mo-	
torcycle: 1ft-33ft / Pedestrian: 1ft-	
3ft / Pedestrian: 1ft-23ft	
-35V	
Radar Sensors: IP65 / Cables: Not	
/aterproof	
200mA	
-40°C ~ +85°C	






#### *In The Box*

1 x Control Module / 1 x Power Harness / 2 x Radar Sensor 2 x LED Indicator / 1 x GPS Module / 1 x Speaker 4 x 3M Velcro Adhesive Pad

#### Installation Guide

Sensors should be placed to the inner corner of the bumper with supplied Velcro. The angle should be between  $20^{\circ} \sim 25^{\circ}$  with the height ranging from 13-35 inches.





Note: Sensors do not work with metal bumpers





Step 1: Use a protractor to determine sensor placement. The angle should be between  $20^{\circ} \sim 25^{\circ}$  with the high ranging from 13-35 inches.

Step 2: Locate the desired position for the sensors.




Step 3: Remove the rear bumper to clean the suface for sensors.



Make sure surface is clean before placing velcro


Step 4: Place the provided velcro on the surface of the sensors (black side) and the desired location on the bumper (See image below).



#### Turn Signal Installation

Step 5: Using a voltage multi-meter, locate the left and right turn signal trigger wires behind the tail lamp. Once verified, connect the left and right signal wires of the wire harness to the correct signal wires.







#### LED Indicator Installation

Step 6: Place the LED indicators in view of the driver. Ideally they should be placed on the A-pillar or in field view side mirrors.





#### Speaker Location

Step 7: While installing the speaker, make sure it is not obstructed by any panels inside the vehicle.



Step 8: Tuck the wires neatly to hide and prevent wire pinch.

#### Illumination of the LED Indicator On Control Box

- 1. The LED comes on solid when the system is first powered up.
  - 2. The LED blinks slowly while the GPS module connects.
- 3. The LED blinks quickly while sensing moving objects that are approaching in the blind spot (same frequency as to the alarm LED indicators & the buzzer).
- 4. The LED maintains the last blinking status after the alerts have ended.

#### **Alert Conditions**

- 1) When the vehicle is on, the system would start detecting objects in the blind area in the lane next to/behind the vehicle within 50 feet.
- 2) When vehicles are approaching and their speed is faster than your speed.



#### Right Side Detection

**ALERT CONDITIONS** 

R-LED indicator will be activated when there is an object approaching to the right side blind area of your vehicle. While there will always be visual alerts, audio warnings will only trigger if the turn signal is on.

#### Left Side Detection

L-LED indicator will be activated when there is an object approaching to the left side blind area of your vehicle. While there will always be visual alerts, audio warnings will only trigger if the turn signal is on.

#### **Troubleshooting**

Issue	Reason	Solution
LED light doesn't work	Incorrect connection/	Check connection/replace
	LED light broken	LED light
Opposite LED indicator	Microwave sensor	Make sure RED is driver
	or LED indicators are	side and YELLOW is pas-
	plugged in to the op-	senger side.
	posite connector	
Buzzer does not work	Wrong connection or	Check the harness and
	pins not making con-	make sure connection is
	tact / Defective buzzer	correct / Replace buzzer
	speaker	
Sensors or GPS does	Sensors or GPS mod-	Find the best location
not work	ule are covered by the	where the GPS antenna
	metal bumper or other	cannot be blocked by any
	metal	metal
Unit does not work	. ,	Normal behavior in this
after GPS is connected	not trigger the sensors	case. The GPS needs to
	if the speed is less than	detect more than 20mph
	20mph	to trigger the sensors

#### ONE YEAR WARRANTY

REAR VIEW SAFETY, INC. WARRANTS THIS PRODUCT AGAINST MATERIAL DEFECTS FOR A PERIOD OF ONE YEAR FROM DATE OF PURCHASE. WE RESERVE THE RIGHT TO REPAIR OR REPLACE ANY SUCH DEFECTIVE UNIT AT OUR SOLE DISCRETION. REAR VIEW SAFETY, INC. IS NOT RESPONSIBLE FOR A DEFECT IN THE SYSTEM AS A RESULT OF MISUSE, IMPROPER INSTALLATION, DAMAGE OR MISHANDLING OF THE ELECTRONIC COMPONENTS. REAR VIEW SAFETY, INC. IS NOT RESPONSIBLE FOR CONSEQUENTIAL DAMAGES OF ANY KIND. THIS WARRANTY IS VOID IF: DEFECTS IN MATERIALS OR WORKMANSHIP OR DAMAGES RESULT FROM REPAIRS OR ALTERATIONS WHICH HAVE BEEN MADE OR ATTEMPTED BY OTHERS OR THE UNAUTHORIZED USE OF NONCONFORMING PARTS; THE DAMAGE IS DUE TO NORMAL WEAR AND TEAR, THIS DAMAGE IS DUE TO ABUSE, IMPROPER MAINTENANCE, NEGLECT OR ACCIDENT; OR THE DAMAGE IS DUE TO USE OF THE REAR VIEW SAFETY, INC. SYSTEM AFTER PARTIAL FAILURE OR USE WITH IMPROPER ACCESSORIES.

#### **WARRANTY PERFORMANCE**

DURING THE ABOVE WARRANTY PERIOD, SHOULD YOUR REAR VIEW SAFETY PRODUCT EXHIBIT A DEFECT IN MATERIAL OR WORKMANSHIP, SUCH DEFECT WILL BE REPAIRED WHEN THE COMPLETE REAR VIEW SAFETY, INC. PRODUCT IS RETURNED, POSTAGE PREPAID AND INSURED, TO REAR VIEW SAFETY, INC. OTHER THAN THE POSTAGE AND INSURANCE REQUIREMENT, NO CHARGE WILL BE MADE FOR REPAIRS COVERED BY THIS WARRANTY.

#### **WARRANTY DISCLAIMERS**

NO WARRANTY, ORAL OR WRITTEN, EXPRESSED OR IMPLIED, OTHER THE ABOVE WARRANTY IS MADE WITH REGARD TO THIS REAR VIEW SAFETY, INC. REAR VIEW SAFETY, INC. DISCLAIMS ANY IMPLIED WARRANTY OR MERCHANT-ABILITY OR FITNESS FOR A PARTICULAR USE OR PURPOSE AND ALL OTHER WARRANTIES IN NO EVENT SHALL REAR VIEW SAFETY. INC. LIABLE FOR ANY INCIDENTAL, SPECIAL, CONSEQUENTIAL, OR PUNITIVE DAMAGES OR FOR ANY COSTS, ATTORNEY FEES, EXPENSES, LOSSES OR DELAYS ALLEGED TO BE AS A CONSEQUENCE OF ANY DAMAGE TO, FAILURE OF, OR DEFECT IN ANY PRODUCT INCLUDING, BUT NOT LIMITED TO, ANY CLAIMS FOR LOSS OF PROFITS.

#### **DISCLAIMER**

REAR VIEW SAFETY AND/OR ITS AFFILIATES DOES NOT GUARANTEE OR PROMISE THAT THE USER OF OUR SYSTEMS WILL NOT BE IN/PART OF AN ACCIDENT OR OTHERWISE NOT COLLIDE WITH AN OBJECT AND/OR PERSON. OUR SYSTEMS ARE NOT A SUBSTITUTE FOR CAREFUL AND CAUTIOUS DRIVING OR FOR THE CONSISTENT ADHERENCE TO ALL APPLICABLE TRAFFIC LAWS AND MOTOR VEHICLE SAFETY REGULATIONS. THE REAR VIEW SAFETY PRODUCTS ARE NOT A SUBSTITUTE FOR REARVIEW MIRRORS OR FOR ANY OTHER MOTOR VEHICLE EQUIPMENT MANDATED BY LAW. OUR CAMERA SYSTEMS HAVE A LIMITED FIELD OF VISION AND DO NOT PROVIDE A COMPREHENSIVE VIEW OF THE REAR OR SIDE AREA OF THE VEHICLE. ALWAYS MAKE SURE TO LOOK AROUND YOUR VEHICLE AND USE YOUR MIRRORS TO CONFIRM REARWARD CLEARANCE AND THAT YOUR VEHICLE CAN MANEUVER SAFELY. REAR VIEW SAFETY AND/OR ITS AFFILIATES SHALL HAVE NO RESPONSIBILITY OR LIABILITY FOR DAMAGE AND/OR INJURY RESULTING FROM ACCIDENTS OCCURRING WITH VEHICLES HAVING SOME OF REAR VIEW SAFETY PRODUCTS INSTALLED AND REAR VIEW SAFETY AND/ OR ITS AFFILIATES, THE MANUFACTURER, DISTRIBUTOR AND SELLER SHALL NOT BE LIABLE FOR ANY INJURY, LOSS OR DAMAGE, INCIDENTAL OR CONSEQUENTIAL, ARISING OUT OF THE USE OR INTENDED USE OF THE PRODUCT. IN NO EVENT SHALL REAR VIEW SAFETY AND/OR ITS AFFILIATES HAVE ANY LIABILITY FOR ANY LOSSES (WHETHER DIRECT OR INDIRECT, IN CONTRACT, TORT OR OTHERWISE) INCURRED IN CONNECTION WITH THE SYSTEMS, INCLUDING BUT NOT LIMITED TO DAMAGED PROPERTY, PERSONAL INJURY AND/OR LOSS OF LIFE. NEITHER SHALL REAR VIEW SAFETY AND/OR ITS AFFILIATES HAVE ANY RESPONSIBILITY FOR ANY DECISION, ACTION OR INACTION TAKEN BY ANY PERSON IN RELIANCE ON REAR VIEW SAFETY SYSTEMS, OR FOR ANY DELAYS, INACCURACIES AND/OR ERRORS IN CONNECTION WITH OUR SYSTEMS FUNCTIONS.



If you have any questions about this product, contact:

Rear View Safety, Inc. 1797 Atlantic Avenue Brooklyn, NY 11233 800.764.1028

# Better Cameras. Better Service. IT'S OUR GUARANTEE.

